# Bioinformatics file formats

Jessen V. Bredeson UC Berkeley


### Goals and outline

- Understand importance of standardized file formats
- Introduce you to commonly-used formats in bioinformatics
- Resources for manipulating or parsing them yourself

# Why are (standardized) file formats important?

#### Data sharing and collaboration

File standards provide:
a common language for data sharing,
promote collaboration,
ensure data reusability,
reduce user errors



#### Syntactic and semantic interoperability

"The capability to communicate, execute programs, or transfer data among various functional units in a manner that requires the user to have little or no knowledge of the unique characteristics of those units"<sup>1</sup>


"the capability of different programs to exchange data via a common set of exchange formats, to read and write the same file formats, and to use the same protocols.... the lack of interoperability can be a consequence of a lack of attention to standardization during the design of a program"<sup>2</sup>

- 1. ISO/IEC 2382-01 Information Technology Vocabulary, Fundamental Terms
- 2. Gordon and Hernandez, The Official Guide to the SSCP Book

### We have a specimen of interest...




### We extract DNA...



### Variants

- SNPs: Single-Nucleotide Polymorphisms
- Indels: Small insertions-deletions
- Structural variants: mid-to-large sized insertions, deletions, rearrangements

## Variant-calling workflow



### We have data, now what?

```
$ 1s
Trex_genome.fasta
Trex_genome.annotation.gff3
SAMPLE_NoIndex_R1_001.fastq.qz
SAMPLE_NoIndex_R2_001.fastq.qz
$ head -3 Trex_genome.fasta
>Chr1
ATGCGTACGTATTCTGCGCTATCGCTATCAGCTATCTAGCTACGATCAGCTATCGTACGATCACT
$ gunzip -c SAMPLE_NoIndex_R1_001.fastq.qz | head -4
@HS3:SAMPLF:1:1:1
```

# Index the genome

```
$ bwa index Trex_genome.fasta # creates the following files:
$ ls Trex_genome.fasta*
Trex_genome.fasta
Trex_genome.fasta.bwt
Trex_genome.fasta.pac
Trex_genome.fasta.ann
Trex_genome.fasta.amb
Trex_genome.fasta.sa
$ samtools faidx Trex_genome.fasta # creates Trex_genome.fasta.fai
$ head -3 Trex_genome.fasta.fai
Chr1 217471166 141
                           100 101
Chr2 181034961 219646160 100 101
Chr3 153873357 402491612 100 101
$ samtools dict Trex_genome.fasta >Trex_genome.dict
$ head -3 Trex_genome.dict
@HD VN:1.0 SO:unsorted
@SQ SN:Chr1 LN:217471166 M5:56d95ce6647ea9087b857b1efa6d00dd
@SQ SN:Chr2 LN:181034961 M5:20852c561ea38c67aa67e6d655cfebf2
```

### FASTA/Pearson

https://en.wikipedia.org/wiki/FASTA\_format

>U31202.1 Human noggin (NOGGIN) gene, complete cds GAGCTCCGGCGGGTCAGCCGGACTGTCGGCTTCCCGGGGCATCTGGGTCCGGCGGGGCACAGCCCTGGGC GCTGCCGAAGCCGCCGCCGCCGCCTCCGCGGCGAGTACAGGCGGCTTCCCCGGAGCCTGTGCAGCTCCA GAGAGAGTCAGTGGTTTCCATGGTGATGGAGCTGAAAGTGCAGGAAATTTAAAGGCTTGGACCCTGCGAG ACAGACAAACCGGTGCCAACGTGCGCGGACGCCGCCGCCGCCGCCGCCGCTGGAGTCCGCCGGGCAGAGC AGCGGCCGGNCGAAGAGCAGCGAGAGGAGGAGGGGAGAGCGGCTCGTCCACGCGCCCTGCGCCGCCGCCG GCCCGGGAAGGCAGCGAGGAGCCGGCGCCTCCCGCGCCCCGCGGTCGCCCTGGAGTAATTTCGGATGCCC AGCCGCGGCCGCCTTCCCCAGTAGACCCGGGAGAGGAGTTGCGGCCAACTTGTGTGCCTTTCTTCCGCCC CGGTGGGAGCCGCCGCGAAGGGCTCTCCCGGCGGCTCATGCTGCCGGCCCTGCGCCTGCCCAGCC GACGCGGGACGAAGCAGCCCCGGGCGCGCGCCAGAGGCATGGAGCGCTGCCCCAGCCTAGGGGTCAC AGGAAAAGGATCTGAACGAGACGCTGCTGCGCTCGCTCGGGGGGCCACTACGACCCAGGCTTCATGGC AGGGCTTGGCCCAGGGCAAGAAGCAGCGCCTAAGCAAGAAGCTGCGGAGGAAGTTACAGATGTGGCTGTG GTCGCAGACATTCTGCCCCGTGCTGTACGCGTGGAACGACCTGGGCAGCCGCTTTTGGCCGCGCTACGTG AAGGTGGGCAGCTGCTTCAGTAAGCGCTCGTGCTCCGTGCCCGAGGGCATGGTGTGCAAGCCGTCCAAGT ACTTGATCCTCGAGCTC

### FASTA/Pearson

FASTA Defline: Sequence ID + Description on same line, sequence string on the next

>U31202.1 Human noggin (NOGGIN) gene, complete cds -

"greater than"
Start of record

Sequence ID

Required;
Any printable
non-whitespace
characters:

[!-~]

Whitespace only required if description present

GASCTCCGGCGGGTCAGCCGGACTGTCGGCTTCCCGGGGGCATCTGGGTCCGGCGGGGCACAGCCCTGGGC **&**CTGCCGAAGCCGCCGCCGCCCCCCGCGGCGAGTACAGGCGGCTTCCCCCGGAGCCTGTGCAGCTCCA GAGAGAGTCAGTGGTTTCCATGGTGATGGAGCTGAAAGTGCAGGAAATTTAAAGGCTTGGACCCTGCGAG ACAGACAAACCGGTGCCAACGTGCGCGGACGCCGCCGCCGCCGCCGCTGGAGTCCGCCGGCAGAGC AGCGGCCGGNCGAAGAGCAGCGAGAGGAGGAGGGGGAGAGCGGCTCGTCCACGCGCCCTGCGCCGCCGCCG GCCCGGGAAGGCAGCGAGGAGCCGCCCTCCCGCGCCCCGCGGTCGCCCTGGAGTAATTTCGGATGCCC AGCCGCGGCCGCCTTCCCCAGTAGACCCGGGAGAGGAGTTGCGGCCAACTTGTGTGCCTTTCTTCCGCCC CGGTGGGAGCCGGCGCTGCGCAAGGGCTCTCCCGGCGGCTCATGCTGCCGGCCCTGCGCCCAGCC GACGCGGGACGAAGCAGCCCCGGGCGCGCCAGAGGCATGGAGCGCTGCCCCAGCCTAGGGGTCAC CGCCCGGCACCCAGCGACAACCTGCCCCTGGTGGACCTCATCGAACACCCAGACCCTATCTTTGACCCCA AGGAAAAGGATCTGAACGAGACGCTGCTGCGCTCGCTCGGGGGGCCACTACGACCCAGGCTTCATGGC AGGGCTTGGCCCAGGGCAAGAAGCAGCGCCTAAGCAAGAAGCTGCGGAGGAAGTTACAGATGTGGCTGTG GTCGCAGACATTCTGCCCCGTGCTGTACGCGTGGAACGACCTGGGCAGCCGCTTTTGGCCGCGCTACGTG AAGGTGGGCAGCTGCTTCAGTAAGCGCTCGTGCTCCGTGCCCGAGGGCATGGTGTGCAAGCCGTCCAAGT CCAGTACCCCATCATTTCCGAGTGCAAGTGCTCGTGCTAGAACTCGGGGGCCCCCTGCCCGCACCCGGAC

Description/Comment
CTGGGC
GCTCCA
Optional;
AACCCC
Free-form text

\_ FASTA Body/ Sequence string Nucleotide, amino acid, IUPAC codes, alignment

Should be wrapped flush, but sometimes is not

characters [-\*]

FASTA files are best suffixed with ".fasta" or ".fa"; some tools require this.

CCATTAA

ACTTGATCCTCGAGCTC

#### https://en.wikipedia.org/wiki/FASTQ\_format

FASTQ Sequence Header: Sequence ID + Description on same line, sequence string on the next

Whitespace only required if description present

"At" symbol

**Description/Comment** optional GGATCTATGGCCATGTAGGGACCATCTGAAGGCAGATCAAAATTTCGCTGAGCAAATTTAGGGTCCGGGTTTGTT

Start of sequence portion of record

**Sequence ID** 

Required; Any printable non-whitespace characters

[!-~]

FASTQ Sequence

Nucleotide, amino acid, IUPAC codes

> Should not be wrapped flush

FASTQ files are best suffixed with ".fastq" or ".fq", some tools require this.

#### FASTQ Sequence Header: Paired-end or mate-pair reads

CATTTTTCCAAACATACC

<FFFJFFNJFJJJJ-F-<FJ7JJFJJF<F-7A-7FJ-<FJJ<<FJFFJJFJ<

Read 2

Read 1

FASTQ Qualities Header: Same as Sequence Header, or absent completely

"Plus" symbol\_ Start of qualities portion of record

Qualities ID
Optional;
If present, typically same as Sequence
ID; Must follow same rules

### **FASTQ Qualities**

ASCII+offset encoded "Phred" scores.

Must be same length as sequence.

Should *not* be wrapped flush

 $Phred = -10 \bullet \log_{10}(P)$ 

P = fractional probability that the base call is wrong

<b>▼</b> Dec	H	Oct	Chai	r I	<b>↓</b> Dec	Нх	Oct	Html	Chr	<b>↓</b> Dec	Нх	Oct	Html	Chr	l Dec	: Hx	Oct	Html Ch	hr
0				(null)					Space				@					`	N.
1				(start of heading)				a#33;	_				a#65;					a#97;	a
2				(start of text)				a#34;		66			a#66;						b
3				(end of text)				a#35;					a#67;		I				c
4				(end of transmission)				a#36;		68			a#68;					d	d
5				(enquiry)				a#37;		69	45	105	a#69;	E				e	
6				(acknowledge)	38	26	046	@#38;	6	70	46	106	a#70;	F	102	66	146	a#102;	f
7	7	007	BEL	(bell)	39	27	047	@#39;	1	71	47	107	G	G	103	67	147	@#103;	g
8	8	010	BS	(backspace)	40	28	050	&# <b>4</b> 0;	(	72	48	110	H	H	104	68	150	a#104;	h
9	9	011	TAB	(horizontal tab)	41	29	051	)	)	73	49	111	6#73;	I	105	69	151	i	i
10	Α	012	LF	(NL line feed, new line)	42	2A	052	&#<b>4</b>2;</td><td>*</td><td>74</td><td>4A</td><td>112</td><td>a#74;</td><td>J</td><td>106</td><td>6A</td><td>152</td><td>j</td><td>j</td></tr><tr><td>11</td><td>В</td><td>013</td><td>VT</td><td>(vertical tab)</td><td>43</td><td>2B</td><td>053</td><td>&#<b>4</b>3;</td><td>+</td><td>75</td><td>4B</td><td>113</td><td>a#75;</td><td>K</td><td>107</td><td>6B</td><td>153</td><td>k</td><td>k</td></tr><tr><td>12</td><td>С</td><td>014</td><td>FF</td><td>(NP form feed, new page)</td><td>44</td><td>20</td><td>054</td><td>a#44;</td><td>,</td><td>76</td><td>4C</td><td>114</td><td>a#76;</td><td>L</td><td>108</td><td>6C</td><td>154</td><td>a#108;</td><td>1</td></tr><tr><td>13</td><td>D</td><td>015</td><td>CR</td><td>(carriage return)</td><td>45</td><td>2D</td><td>055</td><td>a#45;</td><td>F 1.</td><td>77</td><td>4D</td><td>115</td><td>@#77;</td><td>M</td><td></td><td></td><td></td><td>m</td><td></td></tr><tr><td>14</td><td>E</td><td>016</td><td>so</td><td>(shift out)</td><td>46</td><td>2E</td><td>056</td><td>&#<b>4</b>6;</td><td></td><td>78</td><td>4E</td><td>116</td><td>۵#78;</td><td>N</td><td>110</td><td>6E</td><td>156</td><td>@#110;</td><td>n</td></tr><tr><td>15</td><td>F</td><td>017</td><td>SI</td><td>(shift in)</td><td></td><td></td><td></td><td>6#47;</td><td></td><td>79</td><td>4F</td><td>117</td><td><b>%#79;</b></td><td>0</td><td></td><td></td><td></td><td>o</td><td></td></tr><tr><td>16</td><td>10</td><td>020</td><td>DLE</td><td>(data link escape)</td><td>48</td><td>30</td><td>060</td><td>@#<b>4</b>8;</td><td>0</td><td>80</td><td></td><td></td><td><b>&#80;</b></td><td></td><td></td><td></td><td></td><td>p</td><td></td></tr><tr><td></td><td></td><td></td><td></td><td>(device control 1)</td><td></td><td></td><td></td><td>a#49;</td><td></td><td></td><td></td><td></td><td>Q</td><td></td><td></td><td></td><td></td><td>q</td><td></td></tr><tr><td>18</td><td>12</td><td>022</td><td>DC2</td><td>(device control 2)</td><td>50</td><td>32</td><td>062</td><td>2</td><td>2</td><td></td><td></td><td></td><td>4#82;</td><td></td><td>114</td><td>72</td><td>162</td><td>r</td><td>r</td></tr><tr><td>19</td><td>13</td><td>023</td><td>DC3</td><td>(device control 3)</td><td></td><td></td><td></td><td>3</td><td></td><td></td><td></td><td></td><td><b>&#83;</b></td><td></td><td></td><td></td><td></td><td>s</td><td></td></tr><tr><td>20</td><td>14</td><td>024</td><td>DC4</td><td>(device control 4)</td><td></td><td></td><td></td><td>4</td><td></td><td></td><td></td><td></td><td>۵#8<b>4</b>;</td><td></td><td></td><td></td><td></td><td>t</td><td></td></tr><tr><td>21</td><td>15</td><td>025</td><td>NAK</td><td>(negative acknowledge)</td><td></td><td></td><td></td><td>5</td><td></td><td></td><td></td><td></td><td><u>4</u>#85;</td><td></td><td>I — — ·</td><td></td><td></td><td>u</td><td></td></tr><tr><td></td><td></td><td></td><td></td><td>(synchronous idle)</td><td></td><td></td><td></td><td>a#54;</td><td></td><td>86</td><td></td><td></td><td>4#86;</td><td></td><td>I — — -</td><td></td><td></td><td>v</td><td></td></tr><tr><td></td><td></td><td></td><td></td><td>(end of trans. block)</td><td></td><td></td><td></td><td><u>@</u>#55;</td><td></td><td>87</td><td></td><td></td><td><u>6#87;</u></td><td></td><td></td><td></td><td></td><td>w</td><td></td></tr><tr><td></td><td></td><td></td><td></td><td>(cancel)</td><td></td><td></td><td></td><td>a#56;</td><td></td><td>88</td><td></td><td></td><td>X</td><td></td><td></td><td></td><td></td><td>x</td><td></td></tr><tr><td></td><td></td><td>031</td><td></td><td>(end of medium)</td><td>57</td><td></td><td></td><td>a#57;</td><td></td><td>89</td><td></td><td></td><td>6#89;</td><td></td><td>ı</td><td></td><td></td><td>y</td><td></td></tr><tr><td></td><td></td><td>032</td><td></td><td>(substitute)</td><td>58</td><td></td><td></td><td>6#58;</td><td></td><td></td><td></td><td></td><td>6#90;</td><td></td><td>1</td><td></td><td></td><td>z</td><td></td></tr><tr><td></td><td></td><td>033</td><td></td><td>(escape)</td><td></td><td></td><td></td><td>6#59;</td><td></td><td>91</td><td></td><td></td><td>6#91;</td><td>-</td><td>123</td><td></td><td></td><td>{</td><td></td></tr><tr><td></td><td></td><td>034</td><td></td><td>(file separator)</td><td></td><td></td><td></td><td>4#60;</td><td></td><td></td><td></td><td></td><td>6#92;</td><td></td><td>I — — -</td><td></td><td></td><td> </td><td></td></tr><tr><td></td><td></td><td>035</td><td></td><td>(group separator)</td><td></td><td></td><td></td><td>=</td><td></td><td></td><td></td><td></td><td>6#93;</td><td>-</td><td>I — — -</td><td>. –</td><td></td><td>}</td><td></td></tr><tr><td></td><td></td><td>036</td><td></td><td>(record separator)</td><td>62</td><td></td><td></td><td>></td><td></td><td></td><td></td><td></td><td>a#94;</td><td>^</td><td></td><td></td><td></td><td>~</td><td></td></tr><tr><td>31</td><td>1F</td><td>037</td><td>US</td><td>(unit separator)</td><td>63</td><td>ЗF</td><td>077</td><td>?</td><td>2</td><td>95</td><td>5F</td><td>137</td><td>_</td><td>_</td><td> 127</td><td>7F</td><td>177</td><td></td><td>DEL</td></tr></tbody></table>											

P	Phred
1×10 <sup>0</sup>	0
1×10 <sup>-1</sup>	10
1×10 <sup>-2</sup>	20
1×10 <sup>-3</sup>	30
1×10 <sup>-4</sup>	40
1×10 <sup>-5</sup>	50
1×10 <sup>-6</sup>	60

Source: www.LookupTables.com


 $Phred = -10 \bullet \log_{10}(P)$ 

P = fractional probability that the base call is wrong

```
!"#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_`abcdefghijklmnopqrstuvwxyz{|}~
33
            59
               64
                   73
                                            126
                                 104
0.....9.......40
                S - Sanger
        Phred+33, raw reads typically (0, 40)
        Solexa+64, raw reads typically (-5, 40)
X - Solexa
I - Illumina 1.3+ Phred+64, raw reads typically (0, 40)
J - Illumina 1.5+ Phred+64, raw reads typically (3, 41)
  with 0=unused, 1=unused, 2=Read Segment Quality Control Indicator (bold)
  (Note: See discussion above).
L - Illumina 1.8+ Phred+33, raw reads typically (0, 41)
```

### QA/QC'ing Illumina Reads

```
# Run FASTQ quality assessment tool and generate plots
$ fastqc --threads 2 --extract SRR10178655_1.fastq.gz SRR10178655_2.fastq.gz
# View the FastQC results in Safari (Mac only):
$ open -a Safari.app SRR10178655_1_fastqc/fastqc_report.html
```



# Trim and align Reads

```
# Find adapter sequences in your reads and trim them off
$ java -Xmx500m -jar ./Trimmomatic-0.39/trimmomatic-0.39.jar PE -phred33 \
   -summary SRR10178655.summary SRR10178655_1.fastq.qz SRR178655_2.fastq.qz \
   SRR10178655_1_passed.fastq.qz SRR10178655_1_failed.fastq.qz \setminus
   SRR10178655_1_passed.fastq.qz SRR10178655_2_failed.fastq.qz MINLEN:100 \setminus
   ILLUMINACLIP:./Trimmomatic-0.39/adapters/NexteraPE-PE.fa:2:30:10:2:keepBothReads
# Align the reads to the genome
$ bwa mem -R '@RG\tID:SRR10178655\tSM:Trex\tLB:HAMMOND01\tPL:ILLUMINA' \
   Trex_genome.fasta SRR10178655_1_passed.fastq.qz SRR10178655_2_passed.fastq.qz | \
   samtools view -b - >SRR10178655.bam
# Sort the read alignments by genome coordinate
$ samtools sort -m 1g -o SRR10178655.srt.bam SRR10178655.bam
# Index the BAM file for fast search (creates SRR10178655.srt.bam.bai)
$ samtools index SRR10178655.srt.bam
```

http://samtools.github.io/hts-specs/SAMv1.pdf http://samtools.github.io/hts-specs/SAMtags.pdf

**SAM:** Sequence Alignment/Map format

**BAM:** Binary SAM


**CRAM:** Reference-Compressed SAM (also binary)

```
@HD VN:1.3 S0:coordinate
@SQ SN:ref|NC_001133| LN:230218
@SQ SN:ref|NC_001134| LN:813184
@SQ SN:ref|NC_001148| LN:948066
@SQ SN:ref|NC_001224| LN:85779
@PG ID:bwa PN:bwa VN:0.7.15-r1140 CL:bwa mem ...
@RG ID:SRR10178655 SM:Trex LB:HAMMOND01 PL:ILLUMINA
SRR10178655.85923 163 ref|NC_001133| 1 30 2S7M = 383 392
    ACATTACTC AAA))-*## NM:i:0 MD:i:7 AS:i:7 RG:Z:SRR10178655
SRR10178655.85923 83 ref|NC_001133| 383 60 9M = 1 -392
    ACCTCACAT 7JFFFFFAA NM:i:0 MD:7:9 AS:i:9 RG:7:SRR10178655
```

**SAM Header:** Meta information describing file format and data within. Header lines must start with "@" symbol (and read IDs must not). Tab separated. Reference IDs cannot be "\*", "0", or "="; they have special meaning.

```
Header format version and sort order
                                                                         Read Group
                                                                       Almost required;
                                                      Program
                    VN:1.3 SO:coordinate
                                                                       ID, sample name,
                                                 processing history
                    SN:ref|NC_001133| LN:230218
              @SO
                                                                       and library names,
                                                 (with commands)
              @SQ
                   SN:ref|NC_001134|
                                      LN:813184
                                                                      sequencing platform
              @SO
                   SN:ref|NC 001148|
                                      LN:948066
 Sequence
                   SN:ref|NC_001224|
              @SQ
                                      LN:85779
 Reference
              @PG
                   ID:bwa PN:bwa
                                   VN:0.7.15-r1140 CL:bwa mem
sequence IDs
              @RG
                   ID: SRR10178655
                                   SM:Trex
                                            LB: HAMMONDØ1
and lengths;
                                      refINC 001133
               SRR10178655.85923
                                163
listed in same
                ACATTACTC AAA))-*##
 order as in
                                       refINC 0011331
               SRR10178655, 85923
                 ACCTCACAT
                                      NM:i:0
                                              MD:7:9
   FASTA
```

**SAM Body:** Describes mapping and alignment without the reference. Eleven required fields. Tab separated. Undefined values: "0" for numeric field, a "\*" for non-numeric.



#### **CIGAR AND Bitwise flag field details**

#### **CIGAR** operators

Op Meaning

M : Match

I : Insertion

D : Deletion

= : Sequence match

X : Sequence mismatch

N : Forward-skip query on reference (intron)

H : Query hard clipping

S : Query soft clipping

P : Padded reference

B : Backward-skip query on reference

#### **Example:**

Q: ATGACAGGACAGAT-GA<sup>GG</sup>

R: ATG-CAGGCCAGATTGATA

3M 1I 10M 1D 2S describes same alignment as 3= 1T 4= 1X 5= 1D 2S

#### **Bit Flags**


To add or test for flags, use 2<sup>n</sup> values with bitwise operations:

Add flag(s)	Test for flag(s)	
flags  = 2**0	flags & 1024	# correct
flags  = 2**1	flags > 1024	<pre># incorrect!!</pre>
flags  = 2**6		

# QA/QC'ing Alignments

```
# Mark optical and PCR duplicate read pairs (reduce bias)
$ gatk MarkDuplicates --java-options '-Xmx1G' \
   -MAX_FILE_HANDLES 2000 \
   -I SRR10178655.srt.bam \
   -0 SRR10178655.srt.mdup.bam \
   -M SRR10178655 metrics
# Calculate QA/QC metrics for read quality etc.
$ samtools stats --ref-seq Trex_genome.fasta \
    SRR10178655.srt.mdup.bam >SRR10178655.stats
# Generate the plots
$ plot-bamstats -s Trex_genome.fasta >Trex_genome.gc
$ plot-bamstats -r Trex_genome.gc -p SRR10178655 SRR10178655.stats
# View the FastQC results in Safari (Mac only):
$ open -a Safari.app SRR10178655.html
```

# QA/QC'ing Alignments



13,797,114,082

12,862,420,009

1.21%

(93.2%)

total: mapped:

error rate:

\$ samtools tview SRR10178655.srt.mdup.bam Trex\_genome.fasta

• • •	🁚 jessenbredeson — ssh -Y bredeson@cori.nersc.gov — 128×48
	211 2221 2231 2241 2251 2261 2271 2281 2291
	GGGAGAGAGGGGCGCACAGACAAGGTAGCCTTGCCGGCTAGCAATCCTCAGCGTACTCTACTTTCTGCTGCCTCTGCATTAGCATAGGGAGAGAGA
• · · · · · · · · · · · · · · · · · · ·	YM
<u></u>	
	TC
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	g,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	A.CA
G	
,,,,,,,,,,,g,,,,,,,,,,,,,,,,,,,,,	
	<u>.TTC.C</u> .A
CAA	G ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	• • • • • • • • • • • • • • • • • • •
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
,,,,,,,,,,,g,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	C,,,,,,,,,,,,,,,,,,,,,,,,,,
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
G	TC.C
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
,,,,,,,,,,,g,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,c,,,,,,,,,,,,,,,,,,,,,,,,,t,
G	
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	C
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
G	
	C
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
CG	,,,,,,c,,,,g <sub>_</sub> ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	c,,,,,,,,,,,t,,,,,t,,,,,,,,,,,,,,,
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	C

- \$ samtools view -b -f3 -F3852 SRR10178655.srt.mdup.bam > SRR10178655.srt.mdup.proper.bam
  \$ samtools index SRR10178655.srt.mdup.proper.bam
  \$ samtools tview SRR10178655.srt.mdup.proper.bam Trex\_genome.fasta

• • •	🏦 jessenbred	eson — ssh -Y bredes	on@cori.nersc.gov — 1	28×48	
2181 2191 2201 CCTCTACTTTCTACTGCCTCTGCATTA	2211 2221	2231 2241	2251 2261	2271 2281	2291
RR.					
,,,,,,,,,,g,,,,					
	,,c,,,,,,,,,,,c,,,		,,,,,,,,,,,t,,,,c		,, ,,,,,,,,c,g,,
,,,,g,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,g,t,,,a,,,,,,,	,,,,,,,,,,,t,,,,c		
,,,,,,,,,,,g,,,,,,,,,,,,,,,,,,,,,,,,,,		,,,g,,,,,,,,,,	,,,,,,,,,,,,g,,,,c		
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		T		
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
,,,,,,,,,,g,,,,,,,,,,,,,,,,				• • • • • • • • • • • • • • • • • • • •	
				:,,,,,t,,,,,,,,,,,,,,,	
,,,,,,,,,,g,,,,,,,,,,,				,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
					A
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				G	
					A T
				• • • • • • • • • • • • • • • • • • • •	
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			,, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
				T. ,,,g,,,	
,,,,,,,,,,g,,,,,,,,,,,,,,,					
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,c,c,g,,
					.C. ,,,,g,,,,,
		a	,,,,,,,,,,,,,a,,,,,		,,,,
					,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				
,,,,,,,,,,g,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		,,,,,,,,,,,t,,,,c		
,,,,,,,,,,,g,,,,,,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				,,,,,,,,,,
				,,,,g,,,,,,,,,,,,,,,,,	
C					
CC,	,,,,g,,,,,,,,,c,,,,			.,,,,,,,,,,,,,,,,,t,,,,,,,,,,,,,,,,,,,	
	,,,,,t,,,,,,,,,,,,,				
			,,,,,,,,,,,,,t,,,,,		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			,,,,,,,,,,,c,,,a,,,,,	
,,,,,,,,,cg,,,,,,,,,,,,,					

\$ samtools tview SRR10178655.srt.mdup.proper.bam Trex\_genome.fasta

• • •		🏦 jes	senbredes	on — ssh -\	/ bredeson	@cori.nersc	.gov — 128	×48		
2181 2191	2201		2221	2231	2241	2251	2261	2271	2281	2291
CCTCTACTTTCTACTGCC	ICIGCATTAGCA								CIGCCICIGCA	TTAGCATAGGGAGAGAG
									T	
,,,,,,,,,,g,,,										
	,,,, ,,,,C	,,,,,,,,,,	,,C,,,,,	,,,,,,,,,,		,,,,,,,,,,	,t,,,,c,,	,,,,,,,,,,		,,, <b>,</b> ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	, <b>, , ,</b> , g , , , , , ,	,,,,,,,,,,,	,,C,,,,,	,g,t,,,a,,		,,,,,,,,,,	,t,,,,c,,	, , , , , , , , , , , , , , , , , , ,	,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
CAA		•							,,,,,,,,,,,,	
		,,,,,,,,,,,,		g,,,,,	,,,,,,,,,	,,,,,,,,,,	,,,,,,C,,	, , , , , , , , , ,	,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
,,,,,,,,,,g,,,,g	, , , , , , , , , , , , ,	,,,,,,,,,								
	,,,,,,,,,,,,					• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •			
						+	+	+		
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		C							,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		, , , , , , , , , , , , , , , , , , ,	,,,,,,,,	,,,,,,,,,		,,,,,,,,,,		, , , , , , , , , , , , , , , , , , ,		
							C			A
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,								. G		
,,,,,,,,,					A		C			AT
						• • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •			
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,	,,,,,,,,,,,		,,,,,,,,,,	,,,,,,,,,,	,,,,,,,,,,		,,,,,,,,	,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	,,,,,,,,,,,,									
										,,,,,,,,,,g,,,,
,,,,,,,,,,g,,,,g	,,,,,,,,,,,,	, , , , , , , , , , ,	,,C,,,,,	,,,,,,,,,,		,,,,,,,,,,	,t,,,,c,,	,		
	,,,,,,,,,,,,	,,,,,,,,,,,		,,,,,,,,,,	,,,,,,,,,	,,,,,,,,,,		, , , , , , , , , , ,	,,,,,,,,	,,,,, <mark>,</mark> ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,,	,,,,,,,,,,,	,,,,,,,,,	,,,,,,,,,	,,,,,,,,,	,,,,,,,,,,,	1111111111	,,,,,,,,,,	,,,,,,,,	,,,,,,,,,c,c,g,,
						C.				,,,,,,,t,,,
							C			· · · · · · · · · · · · · · · · · · ·
, , , , , , , , , , , , , , , , , , ,								, , , , , , , , , ,		,, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
C G			,,c,,,a,	,,,,,,,,,,	,,,,,,,,,	,,,,,,,,,,	,a,,,,c,,	,,,,,,,,,,	,,,,,,,,,,,	 
,,,,,,,,,,g,,,,g	•									
	,,,,,,,,,,,,					,,,,,,,,,,,				,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,,,,,,,,,,,							,,,,,,,,,,		
G	,,,,,,,,,,,,									,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	AC	C .		.GGA	G T C	C		. C		
C	,,,,					,,,,,,,,,,	,,,,,,C,,	, , , , , , , , , , , , , , , , , , ,	,,,t,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
				A						C
	,,,,,,,,,,,,		,,,,,,,,,	,,,,,,,,,		,,,,,,,,,,		,,,,,,,,,,		
	,,,,,,,,,,,	,,t,,,,,,,,	,,,,,,,,,			,,,,,,,,,,			,,,,,,,,,,,	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
0			C	11111			, T, , , , , C, ,			***************************************
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,									,,,a,,,,,,	
			,,,,,,,,,				, -, , , , , , , , ,			

### **Call Variants**

```
# Use local assembly of reads on the genome to calculate SNPs and Indels
gatk HaplotypeCaller \
    --minimum-mapping-quality 30 \
    --min-base-quality-score 30 \
    --read-validation-stringency SILENT \
    --reference Trex_genome.fasta \
    --input SRR10178655.srt.mdup.proper.bam \
    --output SRR10178655.vcf
```

http://samtools.github.io/hts-specs/VCFv4.3.pdf

**VCF:** Variant Call Format

Chr1

2192815 .

GG

**BCF**: Binary VCF ##fileformat=VCFv4.2 ##FILTER=<ID=LowQual, Description="Locus is low quality"> ##FILTER=<ID=PASS,Description="Locus passes all filters"> ##FORMAT=<ID=GQ, Number=1, Type=Integer, Description="The Phred-scaled prob. of the genotype"> ##FORMAT=<ID=GT, Number=1, Type=String, Description="Genotype"> ##FORMAT=<ID=AD, Number=R, Type=Integer, Description="Number of observation for each allele"> ##INFO=<ID=DP, Number=1, Type=Integer, Description="Total read depth at the locus"> ##contig=<ID=Chr1,length=217471166> ##contig=<ID=Chr2,length=181034961> ID REF ALT #CHROM POS OUAL FILTER INFO FORMAT Trex 8.826 ./.:0:0,1Chr1 534 Т Α LowQual DP=1 GT:GQ:AD Chr1 1315 G 564.103 PASS DP=51 GT:GQ:AD 110:99:26,25 Chr1 CTC CC 209.026 . GT:GQ:AD 0|1:99:19,12 369655 DP=31 912.199 . DP=36 GT:GO:AD 211:43:0,28,8 Chr1 672396 GTT GT,GGT

DP=64

GT:GQ:AD

0/1:99:46,18

GGTATTTTTAG 253.597 .

VCF Metadata Lines: For humans and computers. Required by most tools to pre-declare how to parse file body correctly. **fileformat Meta**FILTER Meta

Required on first line; explicitly defines soft -Tells tools how to interpret rest of file filters one expects to see ##fileformat=VCFv4.2 in the FILTER column ##FILTER=<ID=LowQual, Description="Locus is low quality"> \_ ##FILTER=<ID=PASS,Description="Locus passes all filters"> ##FORMAT=<ID=GQ, Number=1, Type=Integer, Description="The Phred-scaled prob. of the genotype"> ##FORMAT=<ID=GT, Number=1, Type=String, Description="Genotype"> ##FORMAT=<ID=AD, Number=R, Type=Integer, Description="Number of observation for each allele"> ##INFO=<ID=DP, Number=1, Type=Integer, Description="Total read depth at the locus"> ##contig=<ID=Chr1,length=217471166> ##contia=<ID=Chr2,length=181034961> #CHROM POS OUAL FILTER INFO **FORMAT** DP=1 Chr1 534 8.826 Low0ual GT:GO:AD DP=51 GT: GOFORMAT9Meta25 Chr1 1315 564.103 PASS 209. INFO. Meta DP=31 Chr1 TExplicitly defines the Chr1 Explicitly defines the = 36 672396 types data to be GT, GGT Chr1 types of Key=Value P=64 21 conting Meta observed in sample Optional, encouraged; data to be observed in column(s) Describes reference sequences INFO column

observed in CHROM column

**VCF Header Line:** Defines columns, including the sample names. Required by most tools to parse file correctly; undefined fields set to "."

```
Locus ID
                                                           Locus-Level Meta
                           if applicable
Chromosome name
                                                              Information
                       e.g., DBsnp ID, etc.
                                           is low quality" Key=Value pair info
    and Position
Sequence IDs should cription Locus
                                       Locus-level iteabout the locus (and all
#be in conting Meta; ber=1, Type=Intege Quality: Score "The samples: at the locus) the genotype ">
#PositionsID=basedber=1, Type=String Phred-scaled Genotype">
##FORMATA<ID=AD, Number=R, Type=Integrob ethat locus is umber of object at locus is umber of object at locus is umber of object at locus.
        ID=DP, Number=1, Type=Integernot really ivariant tal read depth at the locus">
       1a=<ID=Chr1.lenath=217471166>
##cortig=xID=Chr2,length=181034961>
                                         QUAL
                                                             INFO
                                                                    FORMAT
#CHROM
                                                   FILTER
                                                                               Trex
                      REF ALT
                                                                               ./.\0:0,1
                                                                    GT:GO:AD
                                                   Low0ual
                                                             DP=1
Chr1
        534
                                                                    (T:GO:AD
Chr1
         1315
                                                   PASS
                                                             DP=31 /GT:GO:AD
                                                                               0|1:99:19.12
                                   Locus-level
Chr1 Reference and
                                                           Sample-Level AD
                                                                               2 | Sample Field
                                                                               Contains sample
Chr Alternate Alleles G
                            GGTATTTSoft Filter(s)
                                                         Field Formatting
                              "PASS" = passes filters
  Alleles observed in
                                                           Ordered list of
                                                                                 genotype and
                              "." = no filters applied
  reference sequence
                                                          fields present in
                                                                                associated info
                              anything else = failure
  and samples at the
                                                              samples
                                                                                  at the locus
          locus
```

**VCF Loci:** Tab-delimited columns. Alleles indexed from 0 (REF) to N (ALT) alleles. Genotypes represented with those indices

```
##fileformat=VCFv4.2
##FILTER=<ID=LowQual, Description="Locus is low quality">
##FILTER=<ID=PASS, Description="Locus passes all filters">
##FORMAT=<ID=GO, Number=1, Type=Integer, Description="The Phred-scaled prob. of the genotype">
##FORMAT=<ID=GT, Number=1, Type=String, Description="Genotype">
*Substitution\locuser=R,TyComplex locusiption="Number of observation for each allele">
##INFO=<ID=DP, Number=1, Type=InMultirablele; iption="Total read depth at the No=call or hard-
##contig=<ID=Chr1,\engtheletion1and substitution!
                                                                         filtered genotype
##contia=<ID=Chr2,length=181034961
                    REF
#CHROM
        POS
                          ALT
                                        OUAL
                                                 FILTER
                                                          INFO
                                                                 FORMAT
                                                                           Trex
                                        8.826
                                                 LowQual
                                                                            ./.:0:0,1
Chr1
        534
                          Α
                                                          DP=1
                                                                 GT:GQ:AD
                          G
                                                                           110:99:26,25
Chr1
        1315
                                        564.103
                                                 PASS
                                                          DP=51
                                                                 GT:GQ:AD
Chr1
        369655
                     CTC
                                        209.026
                                                          DP=31
                                                                 GT:GQ:AD
                                                                           0|1:99:19,12
                                                                           2|1:43:0,28,8
Chr1
        672396
                          GT, GGT
                                        912.199
                                                          DP=36
                                                                 GT:GQ:AD
                     GTT
        2192815
                                                                 GT:GQ:AD
                                                                           0/1:99:46.18
Chr1
                     GG
                          GGTATTTTTAG
                                       253.597
                                                          DP=64
                                               Phased genotypes
Deletion locus
                                                                             Allele Depth
                                                                             Read count for
                                             Unphased genotype
```

each allele

**Insertion locus** 

### **Annotation files**

### **BED**


#### https://genome.ucsc.edu/FAQ/FAQformat.html#format1

**BED:** Browser Extensible Data format

```
track itemRgb="On"
Chr1
     0
             126500
                            0 + 0
                                          126500
                     CLEAR1
                                                  0,0,0
     126500
            128500
                     BREAK1
                            0 +
                                 126500
                                          128500
                                                  213,221,213
Chr1
Chr1
     128500
             278000
                     CLEAR2
                            0
                               +
                                 128500
                                          278000
                                                  0,0,0
                     BREAK2
     278000
             280000
                            0 + 278000
                                          280000
                                                 213,221,213
Chr1
Chr1
     280000
             362500
                     CLEAR3
                            0 + 280000
                                          362500
                                                  0,0,0
Chr1
     362500
             366000
                     BREAK3
                            0
                               +
                                 362500
                                          366000
                                                 213,221,213
     366000
Chr1
             427500
                     CLEAR4
                                  366000
                                          427500
                                                  0,0,0
                     BREAK4
     427500
             429500
                               + 427500
                                          429500
                                                 213,221,213
Chr1
                            0
Chr1
     429500
             599500
                     CLEAR5
                               + 429500
                                          599500
                                                  0,0,0
     599500
Chr1
             605500
                     BREAK5
                                  599500
                                          605500
                                                  213,221,213
                            0 +
```

### **BED**

BED: Columns tab-delimited. First three required, all others optional (first 6 typical).



### GFF3

https://github.com/The-Sequence-Ontology/Specifications/blob/master/gff3.md

**GFF:** Generic Feature Format

```
##aff-version 3
##species http://www.ncbi.nlm.nih.gov/Taxonomy/Browser/wwwtax.cgi?id=436495
##genome-build RexBase Trex1
##sequence-region Chr1 1 217471166
# Note Trex_genome.fasta, complete genome
Chr1 Gnomon gene
                                78350
                                                 ID=gene32251; Name=L0C101732307
                          43895
Chr1 Gnomon
             mRNA
                          43895 78350
                                                ID=rna61088; Name=XM_012954515.1; Parent=gene32251
             CDS
                                                ID=rna61088.1.CDS;Parent=rna61088
Chr1 Gnomon
                          43895 43947
                                                ID=rna61088.1.exon; Parent=rna61088
Chr1 Gnomon
                          43895 43947
            exon
Chr1 Gnomon
            start_codon
                         43895 43897
                                                ID=rna61088.1.start_codon;Parent=rna61088
                                           +
                                             1 ID=rna61088.2.CDS;Parent=rna61088
             CDS
                          48839 49007
Chr1 Gnomon
                                          +
                                                ID=rna61088.2.exon; Parent=rna61088
Chr1 Gnomon
                          48839 49007
             exon
                          53889 54000
                                             0 ID=rna61088.3.CDS;Parent=rna61088
             CDS
Chr1 Gnomon
                          53889 54000
                                            . ID=rna61088.3.exon; Parent=rna61088
Chr1 Gnomon
             exon
             CDS
                          55055 55173
                                        . + 2 ID=rna61088.4.CDS;Parent=rna61088
Chr1
     Gnomon
                          55055 55173
                                                 ID=rna61088.4.exon; Parent=rna61088
Chr1
     Gnomon exon
```

### GFF3

**GFF Header:** Pragma begin with "#", comments with "#". Format pragma required for GFF3, highly-recommended for GFF2/GTF.

#### **Pragma/Directives**

Pre-declared set of pragma with specific formats/definitions.

Mostly for computers/browsers.

```
##aff-version 3
##spectes http://www.ncbi.nlm.nih.gov/Taxonomy/Browser/wwwtax.cgi?id=436495
##genome-build RexBase Trex1
##sequence-region Chr1 1 217471166
# Note Trex_genome.fasta, complete genome
Chr1 Gnoman gene
                           43895
                                                  ID=gene32251; Name=L0C101732307
ChrFormatiVersion
                           43895
                                                  ID=rna61088; Name=XM_012954515.1; Parent=gene32251
                                                  ID=rna61088.1.CDS;Parent=rna61088
                           43895
  Pragma/Directive
                                  Comments
                           43895
                                                  ID=rna61088.1.exon; Parent=rna61088
 Required for GFF3, don
                           43895
                                                  ID=rna61088.1.start_codon;Parent=rna61088
                                 Free-form text
                           48839
                                                  ID=rna61088.2.CDS; Parent=rna61088
highly-recommended
                                  for humans,
                           48839
                                                  ID=rna61088.2.exon; Parent=rna61088
for GFF2/GTF formats
                           53889
                                                  ID=rna61088.3.CDS; Parent=rna61088
                                  5ignored by ∅
                                                  ID=rna61088.3.exon; Parent=rna61088
                                    parsers.
                                                  ID=rna61088.4.CDS; Parent=rna61088
                                                  ID=rna61088.4.exon; Parent=rna61088
      Gnomon exon
```

### GFF3

**Feature Attributes** 

Semi-colon separated

GFF Features: Nine tab-delimited fields required. Null values a "."

```
Feature Strand
                                                                              Key=Value pairs;
      Reference ID
                                                   either "+" or "-",
                                                                          reserved keys begin with
                                Feature Type
Chromosome/scaffold ID
                                                      or "." if no
                                                                               capitals letters;
                             Must be SO term or
    May only contain
                                                    strand applies
                                                                          "Parent" attribute defines
                              accession number
    characters in set:
                                                                         feature hierarchy; must use
 [a=zA-Z0-9::^*$@!+ ?-|1
                                    Score
                                                                              URL-escaping for
                                                        /www.tax.cai?id=436495
                                 floating point
                                                                            forbidden characters
                            complete gend
                                                    ID=gene32251; Name=L0C101732307
                             43895
        Gnomon
                                    78350
                aene
                mRNA
                             43895
                                    78350
                                                    ID=rna61088; Name=XM_012954515.1; Parent=gene32251
  Chr1
        Gnomon
                                                    ID=rna61088.1.CDS; Parent=rna61088
        Gnomon
                CDS
                             43895
                                    43947
  Chr1
                                                    ID=rna61088.1.exon; Parent=rna61088
  Chr1
        Gnomon
                             43895
                                    43947
                exon
                start_codon
                             43895
                                    43897
                                                    ID=rna61088.1.start_codon;Parent=rna61088
        Gnomon
  Chr1
                                                       rna61088.2.CDS; Parent=rna61088
        Gnomon
                                                          61088.2.exon; Parent=rna61088
        Gnomon Source
                                                             88.3.CDS; Parent=rna61088
                                   Start and End
       sually the program or 889
                                                              8.3.exon;Parent=rna61088
                                    55Positions<sup>2</sup>
                                                      Codon Phase arent=rna61088
        organization that
                                                    in either 0, 1; expraparent=rna61088
                                       1-based
    generated the annotations
                                   coordinates on
                                                       Offset to next
                                      "+" strand
                                                      codon position
```

### Resources

### File manipulation/filtering

pysam (API)	FASTA/Q, BED, B/CR/SAM, B/VCF	https://pysam.readthedocs.io/en/latest/api.html#sam-bam-cram-files
pyFaidx (API)	FASTA	https://doi.org/10.7287/peerj.preprints.970v1
Seqtk	FASTA/Q	https://github.com/lh3/seqtk
Seqkit	FASTA/Q	https://doi.org/10.1371/journal.pone.0163962
seqmagick	Many	https://seqmagick.readthedocs.io
bedtools	BAM, BED, GFF, VCF	https://bedtools.readthedocs.io
bcftools	VCF/BCF	https://samtools.github.io/bcftools
genometools	FASTA/Q, GFF3	http://genometools.org
samtools	FASTA/Q, B/SAM	https://github.com/samtools/samtools
vcftools	VCF/BCF	https://vcftools.github.io/man_latest.html

### Resources

### QA/QC, Adapter and Quality trimming

trimmomatic	FASTQ	http://usadellab.org/cms/?page=trimmomatic
FastQC	FASTQ, B/SAM	https://www.bioinformatics.babraham.ac.uk/projects/fastqc/
Sickle	FASTA/Q	https://github.com/ucdavis-bioinformatics/sickle
Scythe	FASTA/Q	https://github.com/ucdavis-bioinformatics/scythe
Sabre	FASTA/Q	https://github.com/najoshi/sabre
cutadapt	FASTA/Q	https://cutadapt.readthedocs.io/en/stable/

### Alignment

minimap2	FASTA/Q	https://github.com/lh3/minimap2
BWA	FASTA/Q	https://github.com/lh3/bwa
bowtie2	FASTA/Q	http://bowtie-bio.sourceforge.net/bowtie2/index.shtml
STAR	FASTQ	https://github.com/alexdobin/STAR
GMAP	FASTA/Q	http://research-pub.gene.com/gmap/
exonerate	FASTA	https://www.ebi.ac.uk/about/vertebrate-genomics/software/exonerate

### Resources

### Variant calling

FreeBayes	BAM, VCF	https://github.com/ekg/freebayes
GATK4	FASTA/Q, B/CRAM, VCF	https://software.broadinstitute.org/gatk/documentation
DeepVariant	FASTA/Q	https://github.com/google/deepvariant
vg	FASTA/Q	https://github.com/vgteam/vg

### Common file issues

- Non-printable characters
- Non-ASCII encoded characters
- Incorrect formatting (spaces instead of tabs)
- Truncated files

